

SELECTABLE CHAINWINDER OPENING (100mm and 150mm)

FITTING INSTRUCTIONS

PIN_Q50055 Iss: A 1014

1

Stop clip is only to be used for restricting the opening length of chain to 100mm or 150mm.

Identify desired restriction length of 100mm or 150mm marked on underside of product as shown.

2

Ensure chain is completely wound in.

Insert stop clip as shown.
NOTE: 100mm stop location illustrated.

3

Push stop clip into the chain as shown.

Stop clip to be inserted prior to unit being secured down.