


# Lockwood 334 Series Padlock featuring the Rapid Change Shackle

The new brass 334 series padlock provides convenience and flexibility, with an interchangeable shackle.



## Step 1

Fit the 334 series padlock into the jig.



## Step 2

Press down on the face of the padlock. The key will turn and release the shackle.



## Step 3

Insert a suitable Lockwood shackle back into place. Remove padlock from jig.



**LOCKWOOD**

**ASSA ABLOY**

ASSA ABLOY, the global leader  
in door opening solutions